

HOW TO FLASH A ROM TO THE KONAMI FLASH KIT FROM MSX

- You must have a Device where you can stock this Konami ROM file.
You can use MSX Hard Drive, Msx SD Card cartridge, MSX CF cartridge, or Floppy Disk...

You must use MSXDOS to access Flash software.

Copy the files
- FLK4.COM
and the ROM file you want to flash to your device.

Insert the Board in slot 1 or Slot 2 of the MSX.
Leave JP1 open
Boot the MSX to MSXDOS

Close JP1 to enable the Board
Type on Keyboard :
FLK4 <Rom_file_name> /Sxx

Sxx is the slot number where you inserted the cartridge.

Example : FLK4 castlevania.rom /S02

The flashing process must start...
Reset MSX to play The game at the end of the flashing.

You may install an ON/OFF switch on JP1 for easiest use, for multi flashing purpose.