

HOW TO FLASH 2048 ROM FROM MSX

- You must have a Device where you can stock this 2048K ROM file.
You can use MSX Hard Drive, Msx SD Card cartridge, MSX CF cartridge...

You must use MSXDOS to access Flash software.

Copy the files

- BLOC2ASC.COM

- FL2048.COM

-FLLOAD.COM

and the ROM file you want to flash to your device.

Insert the Board in slot 1 or Slot 2 of the MSX.

Leave JP1 open

Boot the MSX to MSXDOS

Close JP1 to enable the Board

Type on Keyboard :

FL2048 <Rom_file_name> /Sxx

Sxx is the slot number where you inserted the cartridge.

Example : FL2048 PFIGHTIN.ROM /S02

The flashing process must start....

Reset MSX to play The game at the end of the flashing.

HOW TO FLASH 2 x 1024 K ROM FROM MSX

- You must have a Device where you can stock this two 1024F ROM files.
You can use MSX Hard Drive, Msx SD Card cartridge, MSX CF cartridge...

You must use MSXDOS to access Flash software.

Copy the files

- BLOC2ASC.COM

- FL2048.COM

-FLLOAD.COM

and the ROM files you want to flash to your device.

Insert the Board in slot 1 or Slot 2 of the MSX.

Leave JP1 open

Boot the MSX to MSXDOS

Close JP1 to enable the Board

Open JP2 to Select Bank1

Type on Keyboard :

FLLOAD <Rom_file_name> /Sxx

example : FLLOAD alestegai.rom /S01

After this part is finish

Close JP2 to Select Bank 2

Type on Keyboard :

BLOC2ASC <Rom_file_name> /Sxx

Example : BLOC2ASC Feedback.ROM /S01

Now you can boot MSX on BANK 1 or BANK 2 by Switching with JP2.

You may install an ON/OFF switch on JP2 for easiest selection.